




GOOPER GHOST

SLUDGE BUCKET™

ACTION FIGURE




WE REALLY DO CARE!


We make each toy with tender loving care. If there is a problem with your toy as you receive it, please let us know. Simply describe the problem and mail that description along with your name and address to:

KENNER PRODUCTS
Consumer Affairs Dept.
1014 Vine St.
Cincinnati, OH 45202


Kenner*
®




ASSEMBLY AND OPERATION



2. Insert lever end of tongue section through hole in back of mouth being careful to align peg on tongue with hole in back of mouth.




3. Shift tongue lever back and forth to create "licking chops" tongue action.



4. Fill mouth with Ecto-Plazm™ Play Gel.




5. By pushing down on tail section with slow intervals, the Gooper Ghost™ will pump up an Ecto-Plazm™ Play Gel bubble.



CLEANING INSTRUCTIONS

Clean immediately after play.

1. Separate pieces and rinse under tap or soak in warm soapy water.
2. Do not leave Ecto-Plazm™ Play Gel inside toy after play.



ECTO-PLAZM may require kneading to achieve proper consistency. It must be stored in its own can when not in use to prevent drying. ECTO-PLAZM may stick to rugs, fabrics, hair, and may damage wood surfaces. If staining occurs, clean with cold water and a laundry detergent. Non-toxic water soluble gel not a food product.